Zigbee Remote Controller (4 Zone)

SPECIFICATION SHEET

ZigBee | Alexa | Google Home | 30M Range | 1-4 Zones | Dimmable

POWER SUPPLIES | PROFILES | CONNECTORS | CE | RoHS COMPLIANT | 5 YEAR WARRANTY

■ PRODUCT SPECIFICATION

Connectivity	ZigBee 3.0 protocol
Input Voltage	Battery Powered
Dimmable	Yes : 0.1% - 100%
Independent Zones	1-4
Wireless Range	Up to 30 metres
Colour	White
Operation Frequency	2.4GHz
Operatin Temperature	0-40°C
Relative Humidity	8% to 80%
Warranty	5 years
Certificated	CE + RoHS
Dimensions (mm)	137 x 45 x 13mm
Battery Type	2 x CR2032 Button Batteries

Zigbee Remote Controller (4 Zone)

SPECIFICATION SHEET

▪ PRODUCT DETAILS

Product name	Zigbee Remote Controller
Product code	CT-ZB-REM-4
Description	Zigbee Remote Controller (4 Zone)

▪ PRODUCT DESCRIPTION

Thr wireless wall controller, you can control up to four zones of RGB/RGBW LED tape from a single unit.
Boasting a sleek glass finish and an easy-to-use touch wheel which enables you to select any colour/shade, each channel on this multizone wall controller can be linked to as many wireless receivers as you require. The unit works with RGB and RGBW LED tape, and can work wirelessly via ZigBeeto a range of 30m

▪ PRODUCT Features

- Commercial Grade ZigBee LED Receiver
- Uses latest ZIGBEE 3 protocols
- Works up to 30m away from receiver
- Works with all ZIGBEE devices & hubs
- Extends ZIGBEE network
- Controls single, CCT & RGB/W LED products
- Can be set to 1, 2, 3, or 4 Independent Zones
- Works with Alexa / Google Home
- 6 preset scenes, 5 preset Kelvin, enables to save and recall 7 scenes

▪ Function Indicator



Zigbee Remote Controller (4 Zone)

SPECIFICATION SHEET

▪ Installation Diagram



Note:Before the first use, please remove the protective film on the battery.

▪ Compatible Devices

Zigbee Receiver

4 Zone Wall Controller

Zigbee Remote Controller (4 Zone)

▪ Adding A Remote Controller to Alexa (Hue Bridge)

Hue Bridge Instructions (step 1)

1. Remove the plastic battery cover on the back of the Remote Controller.
2. Check that your LED Strip Lights are turned on.
3. Open the Philips Hue App. Select “Light Setup” → “Add Light” → “Search”.
4. On the Remote Controller, press & hold down the central ‘Power’ button until the Red LED indicator comes on.
5. Now press the ‘WW’ button on the Remote Controller (**DO NOT HOLD DOWN**).
6. When the Remote Controller has paired successfully with your Philips Hue system, the Red LED indicator will flash quickly 6 times. (**The Remote Controller will NOT show on the App**)

Zigbee Receiver instruction (step 2)

7. On your Zigbee Receiver, connected to your LED Strip Lights, press the black ‘Prog’ button 3 times (**DO NOT HOLD DOWN**). The LED Strips Lights will start to flash slowly.
8. On the Remote Controller, now choose and press the Lighting Zone number to which you wish to connect your LED Strip Lights (1-4). (**Red indicator will stay on**)
9. Now press & hold down the central ‘Power’ button until the Red LED indicator comes on.
10. Immediately press the ‘CW’ button on the Remote Controller (**DO NOT HOLD DOWN**).
11. The Red LED indicator will flash quickly 4 times (Lights will flash twice) to show it has successfully connected to the Zigbee Receiver.

Your system is now fully set up. You can control your lighting using the Philips Hue App, Amazon Alexa App, Wall Controller and your Amazon Alexa Device.

▪ Factory Reset Receiver